

# FITTING INSTRUCTIONS

## String Courses – rendered buildings

1. Fix a treated timber batten to the face of the building to the thickness of the render base coat
2. Base coat render the building and when dry fix the DYNNAMIX mounting strip(s) to the timber. Ensure that the mounting strip(s) are level.
3. Offer the string course up to the DYNNAMIX mounting Strip(s) and ensure the string course is level. If the string course is not level slacken the fixing screws and level the mounting strip(s).
4. Apply a bead of DYNNAMIX adhesive to the inside of the fixing slot on the back of the string course and on the inside of the overlap joint.
5. Offer the string course up to the DYNNAMIX mounting strip(s) and fully push home.
6. Allow DYNNAMIX adhesive to cure and then apply the top coat of the render system to the building (ensure that the string course is protected during this operation).
7. When the render system has hardened, fully seal the string course using a high quality silicone sealant.

